

## Bluewater R/C Flyers

### FLYING and SAFETY RULES (rev 1)

Jan 2023

1. All members flying RPAS must have on their person, proof of current MAAC membership and club membership. Non-member guests flying model aircraft must have on their person, proof of current MAAC .
2. Members or guests, who have not completed the wings training program, are not allowed to fly unless accompanied by a Club member who is a qualified pilot.
3. All transmitters using 72 mhz must have attached, proper channel identification displayed on the antenna.
4. The frequency control system at the flying field must be used at all times if the transmitter is using 72 mhz
5. **All Engines, sizes 0.15 cu. in. displacement (inclusive) and over, must be provided with adequate mufflers.**
6. Each member is responsible for ensuring the flying field is in a neat and debris-free condition at all times.
7. RPAS models may only taxi away from the pit area, or on the flight line. **Model aircraft must not taxi into the pit area.**
8. All RPAS must take off and land in the same direction. Those at the field will designate the active runway direction.
9. Flyers are not allowed to stand on runways while flying. Flyers must stand on the flight line separated by 10 meters, as defined by the cement patio stones.
10. All RPAS models must remain North of the flight line during flight.
11. Low passes may be flown only over runways or open field areas.
12. All spectators **MUST** keep well back of the flight line.
13. All cars **MUST** be parked in the specified area
14. Flying operations must cease when piloted aircraft are in the area.
15. **NOTICE.** This flying field is intended for RPAS models **ONLY.**